



1640 E Francis St., Ontario CA 91761 | P: 909.930.1300 | [www.FealSuspension.com](http://www.FealSuspension.com)

Congratulations on the purchase of Feal 441 Coilovers specifically set up for your vehicle and driving needs.

The spring preload is typically set to 3mm and the spring preload collars have been tightened.

The damping settings are typically set to 15 clicks from full hard.

Check to make sure the ride height of your vehicle is to your liking after installation. **Tighten the ride height collar using the supplied spanner wrenches.** We recommend tapping the end of the wrench with a hammer to tighten the collar.