



3496 Hwy 2 #282 Wrightwood, CA 92397 | P: 909.930.1300 | [www.FealSuspension.com](http://www.FealSuspension.com)

Congratulations on the purchase of Feal 441 Coilovers specifically set up for your vehicle and driving needs. **PLEASE NOTE:**

- Professional installation is recommended. Failure to do so may void warranty. Feal Suspension is not responsible for any damage that may occur due to improper installation.
- The damping settings have been set to 15 clicks from full hard.
- The spring preload has been set to approximately 6mm front/3mm rear and the spring preload collars have been tightened. **Make sure to dial in appropriate droop for your specific chassis.** Refer to "441 Setup guide" in the FAQ section of our website. [www.fealsuspension.com/faqs/](http://www.fealsuspension.com/faqs/)
- Set the preferred ride height of your vehicle by turning the shock body in or out of the lower mount. On MacPherson applications make sure the cartridge engages at least 50mm into the lower mount. On non-MacPherson applications make sure the cartridge engages at least 20mm into the lower mount. **Tighten the ride height collar using the supplied spanner wrenches.** We recommend tapping the end of the wrench with a hammer to tighten the collar.

Please visit [www.fealsuspension.com/faqs/](http://www.fealsuspension.com/faqs/) for further spring preload and tuning information.